














PREPARE THE GROUND, UNWRAP THE PACKAGE,  
LAY OUT THE COMPONENTS, FIND THE TOOLS.



BENTE I 28



LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.






BENTE I 28



MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%





LAY OUT THE **BOTTOM** LOGS,  
**ATTACH** TO THE FOUNDATION.

BENTE I 28




THE WALL **LOGS** WILL HANG OVER  
THE FOUNDATION **BEAMS** BY  
**APPROXIMATELY** 5MM. THIS OVERHANG  
IS DESIGNED AS A RAIN DRIP. **5%**

ATTACH THE FIRST ROW OF WALL LOGS INTO THE BOTTOM LOGS WITH SCREWS.





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

BENTE | 28




SLIDE THE DOOR IN,  
ATTACH THE HANDLE.

BENTE I 28





DON`T FORGET TO  
**TIGHTEN** THE LOGS AFTER  
EVERY 3-4 ROWS.

BENTE | 28



INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

6x140 × 4  
Ø 5 mm






BENTE I 28



INSTALL THE ROOF PURLINS AND ATTACH THEM WITH SCREWS.




6x140 × 6  
Ø 5 mm



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE END OF THE **PURLINS** AND ATTACH WITH 6 SCREWS, 3 INTO **EACH** NEXT, SAW THE LAST **BOARD** TO MAKE IT FIT.

BENTE I 28



4x50  × 132



INSERT FOR THE FASCIA TRIMS  
SCREWS AFTER EVERY 0,5 METERS.

BENTE I 28

4x40  
× 20




EAVES EDGES GO ON TOP OF THE ROOFING\*.

\*(NOT INCLUDED)

BENTE I 28

4x40 × 32




Ø 3 mm



ATTACH ROMBS WITH SCREWS.


BENTE I 28

4x40 × 4  
Ø 3 mm





10 SCREWS INTO THE FIRST FLOORBOARD,  
5 INTO EACH NEXT, SAW THE  
LAST BOARD TO MAKE IT FIT.

4x50  
× 135




BENTE I 28





SAW THE **BASEBOARDS**  
AND ATTACH WITH NAILS  
AT **EVERY 0,5** METERS.




1,4×40  
× 25




BENTE I 28



DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.



BENTE I 28





WINDBOARD




IF DOOR IS TILTED,  
PUSH THE DOOR FRAME SO  
THAT ALL CORNERS ARE 90°.

BENTE I 28



IF **DOORS** ARE IN DIFFERENT HEIGHTS OR THERE IS A GAP **BETWEEN** THEM, **ADJUST** 3 SCREWS ON DOOR HINGES.

BENTE | 28



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

BENTE | 28

