











PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.

CHRISTINA 28



LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.

CHRISTINA 28





MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%

LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.

CHRISTINA 28





5x70 × 6
 6x140 × 10
 Ø 4 mm
 Ø 5 mm





THE WALL **LOGS** WILL HANG OVER
 THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
 IS DESIGNED AS A RAIN DRIP. **5%**

ATTACH THE FIRST ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.


CHRISTINA 28

5×70  $\times 4$ 6×140  $\times 6$
 $\varnothing 4 \text{ mm}$  $\varnothing 5 \text{ mm}$ 





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

CHRISTINA 28




SLIDE THE DOOR IN,
ATTACH THE HANDLE.

CHRISTINA 28




DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

CHRISTINA 28



SLIDE THE WINDOW IN,
ATTACH THE HANDLE.

CHRISTINA 28






INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

CHRISTINA 28

6x140 × 6

Ø 5 mm





INSTALL THE **ROOF** PURLINS AND
ROOF ELEMENTS 1, **ATTACH** THEM
WITH SCREWS.

CHRISTINA 28

6x140
× 20

Ø 4 mm






SCREW RS1 AND RS2 TO PURLINS AND ROOF ELEMENTS.

CHRISTINA 28

6x140
× 32



Ø 5 mm



USE SCREWS TO CONNECT
ROOF SIDES.




CHRISTINA 28

4x50
× 12
Ø 4 mm



SAW ROOFBOARDS SO THAT IT IS POSSIBLE TO ATTACH THEM AGAINST ROOF SIDES.

CHRISTINA 28





AT THE BACK OF THE HOUSE WILL BE A GAP BETWEEN THE ROOFSIDE AND THE ROOFBOARD 79%

PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE **END** OF THE PURLINS AND ATTACH WITH 8 SCREWS, 4 **INTO** EACH NEXT.


CHRISTINA 28

4x50
× 172





10 SCREWS INTO THE FIRST FLOORBOARD,
5 INTO EACH NEXT, SAW THE
LAST BOARD TO MAKE IT FIT.

4x50
× 180






CHRISTINA 28



SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS

1,4X40
× 30





BB


DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x60 × 12

Ø 8 mm





CHRISTINA 28



WINDBOARD



IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90°.

CHRISTINA 28



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

CHRISTINA 28



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

CHRISTINA 28

